



- NOTES:
1. POSITION RHINO BOND PLATES 3-1/2" TO 4" FROM ANGLE CHANGE.
 2. FLASHING MEMBRANE REQUIRES BONDING ADHESIVE.
 3. MULE-HIDE EHD FASTENERS AND RHINO BOND TPO PLATES ARE REQUIRED OVER STEEL AND WOOD DECKS.
 4. THIS METHOD OF MEMBRANE ATTACHMENT IS NOT FOR USE WITH NON-FACED EXPANDED POLYSTYRENE (EPS) OR EXTRUDED POLYSTYRENE (XPS) INSULATION.
 5. THE USE OF 6" OR 10" PS RUSSES IS NOT APPROVED WITH THIS METHOD OF ATTACHMENT.

MULE-HIDE PRODUCTS CO., INC.

RHINO BOND BASE ATTACHMENT SYSTEMS: TPO MECHANICALLY ATTACHED

DETAIL NO.: MHT-RB2
 REVISION DATE: 01/2013