



NOTES:

1. PRIOR TO INSTALLATION OF IN-SEAM TAPE, APPLY MULE-HIDE TAPE PRIMER TO SEAM AREAS.
2. IN-SEAM TAPE IS TO OVERLAPPED A MINIMUM OF 1" (3 cm) AT THE ENDS OF EACH CUT PIECE.
3. INSTALL 3" (8 cm) WIDE IN-SEAM TAPE (IN CONJUNCTION WITH TAPE PRIMER),ALONG THE LEADING EDGE OF THE MEMBRANE SEAM OVERLAPPING EXPOSED SEAM TAPE FROM THE SEAM.
4. CAULK ALL EDGES WITH LAP SEALANT AS SHOWN ABOVE.
5. LOCATE MHE-522 TERMINATION ABOVE ANTICIPATED WATER LEVEL.
6. FOR CORNER APPLICATIONS, SEE DETAILS MHE-514, MHE-515, AND MHE-516.
7. IF A CONTINUATION OF THE DECK MEMBRANE IS TO BE USED AS WALL FLASHING, REFER TO DETAIL MHE-521.

**MULE-HIDE  
PRODUCTS CO., INC.  
2005**

Parapet/Curb With  
Separate EPDM Membrane  
SYSTEMS:  
Fully Adhered 90mil System

DETAIL NO.:  
**MHE-520**