



NOTE:
 REFER TO MULE-HIDE LIVING ROOF™ SYSTEM ATTACHMENT I, II, OR III FOR APPROVED SYSTEM CONFIGURATIONS AND MEMBRANES FOR USE UNDER THE GREENGRID® MODULES

- NOTES:
1. STOP PROTECTION FABRIC MAT AT BASE OF DRAIN.
 2. REMOVE ALL LEAD AND OTHER FLASHING.
 3. ALL BOLTS OR CLAMPS MUST BE IN PLACE TO PROVEDE CONSTANT COMPRESSION ON WATER CUT-OFF MASTIC.
 4. CUT THE MEMBRANE SO IT EXTENDS A MINIMUM OF 1/2" FROM THE ATTACHMENT POINTS OF THE DRAIN CLAMPING RING.
 5. HOLE IN MEMBRANE MUST MEET OR SLIGHTLY EXCEED SIZE OF DRAIN PIPE.
 6. ROOF DRAIN SIZE AND NUMBER OF DRAINS SHALL BE IN ACCORDANCE WITH LOCAL CODES.

**MULE-HIDE
 PRODUCTS CO., INC.**
 AUGUST 2008

**ROOF DRAIN
 SYSTEMS:**
LIVING ROOF FEATURING GREENGRID®

DETAIL NO.:
MHGG-130