



NOTES:

1. ALL FIELD SEAM MUST BE 6" WIDE.
2. A MINIMUM OF 2 PERIMETER SHEETS MUST BE USED.
3. ALL PERIMETER SHEETS MUST BE ATTACHED 12" O.C. MAXIMUM.
4. EXTEND FASTENERS TO OUTSIDE AT ALL CORNERS. FASTENERS MAY BE INSTALLED THROUGH TOP OF MEMBRANE AND THEN PATCHED WITH CURED COVER TAPE.

MH 2.4" SEAM PLATE AND HD FASTENERS
12" O.C. MAX

4' X 8' INSULATION WITH 6 FASTENERS
PER SHEET (MH INSULATION OR APPROVED
COMPATIBLE INSULATION)

**MULE-HIDE
PRODUCTS CO., INC.**
2010

PERIMETER SHEET ATTACHMENT

SYSTEMS:

MECHANICALLY ATTACHED

DETAIL NO.:

MHE-191