



NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING.
2. PIPE FLASHING MUST HAVE INTACT RIB AT TOP EDGE, REGARDLESS OF PIPE DIAMETER.
3. DECK FLANGES OF THE MOLDED PIPE FLASHING SHALL NOT BE OVERLAPPED, CUT OR APPLIED OVER ANY ANGLE CHANGE.
4. 90 MIL MEMBRANE OVERLAY AT CUT IN FIELD MEMBRANE MUST EXTEND 3 INCHES BEYOND MOLDED PIPE FLASHING FLANGE ON 3 SIDES *AND* EXTEND THE LENGTH OF THE CUT IN THE FIELD MEMBRANE AS SHOWN ABOVE.
5. CENTER 9" WIDE UNCURED FLASHING TAPE OVER THE MEMBRANE SPLICE EDGE AND EXTEND 3" BEYOND THE MEMBRANE OVERLAY AS SHOWN ABOVE.
6. CAULK ALL EDGES WITH LAP SEALANT AS SHOWN ABOVE.

**MULE-HIDE
PRODUCTS CO., INC.
2005**

Mule-Hide Molded Pipe Flashing
with Tape

SYSTEMS:
Fully Adhered 90mil System

DETAIL NO.:
MHE-512