



NOTES:

1. TPO MEMBRANE MUST BE PRIMED WITH Si TPO PRIMER BEFORE SETTING FLANGE ON WALL. Si TPO PRIMER IS AVAILABLE IN BLUE OR CLEAR.
2. PITCH PAN MUST BE FASTENED TO SUBSTRATE WITH 1 FASTENER IN EACH CORNER PIECE. PLACE FASTENER IN HOLE FOUND ON INSIDE FLANGE.
3. ShapeShift PITCH PANS CAN BE CONFIGURED INTO THE SHAPE NEEDED BY USING ANY COMBINATION OF CORNER AND STRAIGHT PIECES.
4. VERTICAL PITCH PANS CAN ONLY BE FILLED WITH JTS-1 SEALANT BECAUSE IT DOES NOT SHRINK OR SAG. NO OTHER SEALANTS ARE APPROVED.

**MULE-HIDE  
PRODUCTS CO., INC.**

**ShapeShift  
VERTICAL SEALANT POCKET  
SYSTEMS:**

**ALL TPO SYSTEMS**

**DETAIL NO.:**

**MHT-UN-524**

REVISION DATE: 05/2018