



**NOTES:**

1. ATTACH WOOD NAILER TO WALL/DECK IN ACCORDANCE WITH FMRC GUIDLINES, AS PER SECTION 1-28, REGARDING WINDLOADS TO ROOF SYSTEMS & DECK SECUREMENT.
2. WOOD BLOCKING MAY BE SLOTTED FOR VENTING OF WET-FILL DECKS OR OTHER APPLICABLE CONSTRUCTIONS
3. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE OUTSIDE WALL
4. REFER TO SMACNA RECOMMENDATIONS & DETAILS REGARDING METAL THICKNESS & CLEAT REQUIREMENTS
5. MEMBRANE ENDLAPS MUST BE 6" MINIMUM & FULLY ADHERED AT ALL MEMBRANE IN LOCATIONS WHERE "FAST LAP" IS NOT PRESENT
6. IF INSTALLING A 20-YR SYSTEM, 2 PLIES OF SA BASE SHEET MUST BE INSTALLED.

**MULE-HIDE  
PRODUCTS CO.,INC.  
2003**

**GRAVEL STOP - OPTION 3**

**SELF-ADHERING MOD BIT SYSTEMS**

**DETAIL NO.:  
MH-MB-GS3**