



NOTE: MULE HIDE TAPE PRIMER MUST BE USED PRIOR TO APPLICATION OF IN-SEAM TAPE. FOLLOW PROCEDURE IN MANUAL.

**MULE-HIDE
PRODUCTS CO., INC.**
04/01/2004

MEMBRANE SPLICE
W/ 3" IN-SEAM TAPE

SYSTEMS:
ALL

DETAIL NO.:
MHE-111