



NOTES:

1. PRIOR TO INSTALLATION OF IN-SEAM TAPE, APPLY TAPE PRIMER TO SEAM AREAS.
2. IN-SEAM TAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (3 cm) AT THE ENDS OF EACH CUT PIECE.
3. AT FIELD SEAM INTERSECTIONS, APPLY A 6" x 6"(15 x 15 cm) T-JOINT COVER (UNCURED) FLASHING OVERLAID WITH A 12" x 12" (30 x 30 cm) T-JOINT COVER (SEMI-CURED) FLASHING.
4. INSTALL 3" (8 cm) WIDE IN-SEAM TAPE (IN CONJUNCTION WITH TAPE PRIMER) ALONG LEADING EDGE OF MEMBRANE SEAM OVERLAPPING EXPOSED IN-SEAM TAPE FROM THE SEAM.
5. CAULK ALL EDGES WITH LAP SEALANT AS SHOWN ABOVE.

**MULE-HIDE
PRODUCTS CO., INC.
2005**

Membrane Splice With In-Seam Tape

SYSTEMS:
Fully Adhered 90mil System

DETAIL NO.:
MHE-508