



NOTE: 1. MEMBRANE MUST BE FASTENED UNDER COUNTERFLASHING, DO NOT FASTEN THROUGH COUNTERFLASHING.
 2. ATTACHMENT OF COUNTERFLASHING AS DETERMINED BY SPECIFIER.

**MULE-HIDE
 PRODUCTS CO., INC.
 04/01/2004**

**VERTICAL TERMINATION
 COUNTERFLASHING**

**SYSTEMS:
 ALL**

**DETAIL NO.:
 MHE-173**