

PARAPET WALL FLASHING SURFACE TERMINATION

"Z" STYLE METAL/MATERIAL USED IN CONJUNCTION WITH AN EXTERIOR FINISH MATERIAL (NEW STUCCO, SIDING, ETC.) MAY BE INSTALLED OVER THE FLASHINGS.

THE TOP OF THE SELF-ADHERING MOD BIT FLASHINGS MUST BE MECHANICALLY ATTACHED WITH APPROPRIATE FASTENERS SPACED A MAXIMUM OF 8" ON CENTER. THE FASTENERS MUST PENETRATE AND ANCHOR INTO THE STRUCTURAL WALL (CONCRETE, WOOD, BLOCK, ETC.).

SA-SBS CAP SHEET
OR SA-APP CAP SHEET

8" min

6"

NEW EXTERIOR
FINISH

STUCCO EXTERIOR
FINISH

CAP SHEET MUST TURN UP
THE VERTICAL SURFACE A
MINIMUM OF 4".

MULE-HIDE DOES NOT REQUIRE
BUT RECOMMENDS CANTS
(CANTS ARE OPTIONAL). THE
VERTICAL SURFACE OF THE CAP
SHEET MUST BE SOFTENED OR
MUST BE COATED WITH MOD BIT
FLASHING ADHESIVE PRIOR TO
INSTALLING FLASHING
MATERIAL.

NOTES:

1. VERTICAL SURFACES SUCH AS MASONRY, STUCCO, CONCRETE, AGED WOOD OR METAL SHALL BE PRIMED WITH MULE-HIDE # 121 ASPHALT PRIMER. PRIMER MUST BE THOROUGHLY DRY BEFORE APPLICATION OF SELF-ADHERING MEMBRANES.

**MULE-HIDE
PRODUCTS CO.,INC.
2003**

WALL FLASHING TERMINATION - 3

SELF-ADHERING MOD BIT SYSTEMS

**DETAIL NO.:
MH-MB-WFT03**