



NOTES:

1. REFER TO SPECIFICATION FOR ACCEPTABLE MULE-HIDE FASTENERS AND PLATES.
2. REFER TO MULE-HIDE'S EPDM SPECIFICATIONS FOR SURFACE PREPARATION PROCEDURES FOR EXISTING MEMBRANE.
3. PRIOR TO SEAMING APPLICATION, USE WEATHERED MEMBRANE CLEANER TO PREPARE SURFACES OF TPO AND CLEANED EPDM OR HYPALON MEMBRANES.
4. MULE-HIDE TAPE PRIMER MUST BE USED TO PREPARE MEMBRANE SURFACES PRIOR TO APPLYING MULE-HIDE WHITE MATE-LINE TAPE, IN-SEAM TAPE, AND UNIVERSAL SINGLE PLY SEALANT.

**MULE-HIDE
PRODUCTS CO., INC.**

**TIE-IN TO EXISTING EPDM OR HYPALON
TEAR-OFF SITUATION
SYSTEMS:
ALL TPO SYSTEMS**

DETAIL NO.:
MHT-UN-610C
REVISION DATE: 10/2013