



Powerblanket Lite

AeroWeb, AeroWeb PVC, Helix Max Low-Rise Adhesive



PRODUCT DATA SHEET



TYPICAL PROPERTIES AND CHARACTERISTICS

Temperature Control	Dust, grease, oils, dirt, muck, grime
Product Temperature	Thick grease, heavy dirt and/or algae/fungus, porous surfaces
Voltage	120V
Amps	1.00
Weight	1.8 lbs.
Blanket Dimensions	46" L x 11.25" H
Cylinder Dimensions	12.5" D x 18" H
Packing Size	27" x 13" x 6"
Packing Weight	3 lbs.

DESCRIPTION

Powerblanket Lite cylinder heaters optimize container pressure and increase cylinder efficiency. Powerblanket delivers a barrier of evenly distributed heat to maintain optimal temperatures and improve material yield in cold temperatures. The innovative heat spreading technology insulates, protects, and maintains heat.

BASIC USES

Be sure the work area is free of sharp objects that may puncture or tear the Powerblanket.

- Make sure the side with straps is facing away from the surface requiring heat.
- Be sure to follow product-specific temperature specifications. The Powerblanket is to be used to maintain cylinder warmth to improve spray efficiency and is not meant to alter application temperature limits.
- For storage, remove all debris that may pierce the outer shell. If possible, avoid folding the product. If folding is necessary, avoid creasing and crumpling and follow the folding instructions provided by the manufacturer. Never fold the blanket hot-to-hot and never roll up the product.

BENEFITS AND SUPPLEMENTAL STATEMENTS

- Heats cylinder to a preset 90°F (+/-10°)
- Provides an insulated full-wrap design
- Increases flow rate performance and efficiency of adhesive cylinders
- Saves money by optimizing material usage
- Easy to use
- Certified to UL/CSA/CE standards

STORAGE & HANDLING

- Never roll up the product. When folding, avoid creasing and crumpling by following the folding instructions provided by the manufacturer.
- Never fold hot-to-hot.
- Inspect your Powerblanket for rips, tears, or holes of any kind and inspect the power supply cord for damage before and after every use. Do not apply power to any damaged unit.
- When in use, the product may be placed over warning labels or instructions on other products. Powerblanket warnings and instructions provided only relate to the Powerblanket and should not be used as a substitute for any warnings or instructions on other products used with the blanket.
- Always use a ground fault protection device when using your Powerblanket.
- Never use ungrounded, worn, or damaged extension cords.
- Do not submerge in liquids.
- Never pull, drag, or lift by the power cord.
- Never connect to power when folded.
- Do not place additional covers or insulation over the Powerblanket.
- Do not place heavy objects or walk on the Powerblanket.



Powerblanket Lite

AeroWeb, AeroWeb PVC, Helix Max Low-Rise Adhesive



PRODUCT DATA SHEET

PROTECTION & SAFETY

Mule-Hide maintains Safety Data Sheets on all of its non-exempt products. Safety Data Sheets contain health and safety information for your development of appropriate product handling procedures to protect your employees and customers. Mule-Hide's Safety Data Sheets should be read and understood by all of your supervisory personnel and employees before using Mule-Hide products in your facilities.

ADDITIONAL INFORMATION

The information given on this PDS is subject to change without notice. Always check the Mule-Hide website at www.mulehide.com for the latest information, changes and updates or contact Mule-Hide Products Company at 800-786-1492.

DISCLAIMER

The statements provided concerning the material shown are intended as a guide for material usage and are believed to be true and accurate at the time of printing. No statement made by anyone may supersede this information, except when done in writing by Mule-Hide Products Co., Inc. Since the manner of use is beyond our control, Mule-Hide does not authorize anyone to make any warranty of merchantability or fitness for any particular purpose or any other warranty, guarantee or representation, expressed or implied, concerning this material. This product may be eligible for a Mule-Hide warranty, please check the Mule-Hide website at www.mulehide.com or contact Mule-Hide directly at 800-786-1492 for details. Buyer and user accept the product under these conditions and assume the risk of any failure, any injury person or property (including that of the user), loss or liability resulting from the handling, storage or use of the product whether or not it is handled, stored or used in accordance with the directions or specifications. Mule-Hide must be notified in writing of any claims and be given the opportunity to inspect the alleged failure before repairs are made.