




CREASE PVC COATED METAL FLASHING ALONG DASHED LINES AFTER CUTTING AND REMOVING SHADED TRIANGLE.




OVERLAP FLANGE AT CORNER AND FASTEN TO WOOD NAILERS USING 1-1/4" RING SHANK NAILS SPACED 6" O.C., STAGGERED 1/2".



INSTALL 2" WIDE FOIL TAPE OVER VERTICAL JOINT IN PVC COATED METAL AND OVER CUT EDGE AT CORNER AS SHOWN.



HEAT WELD 6" WIDE PIECE OF REINFORCED PVC MEMBRANE OVER FOIL TAPE.



INSTALL PVC FIELD MEMBRANE AND HEAT WELD TO FLANGE OF PVC COATED METAL. ALSO INSTALL INSIDE CORNER FLASHING PER MULE-HIDE DETAILS MHP-182 OR MHP-183.

NOTE:

1. DETAILS TO BE USED IN CONJUNCTION WITH STANDARD GUIDE SPECIFICATIONS CONTAINING REQUIREMENTS FOR NAILERS, INSULATION, SLIPSHEETS, ETC.
2. PVC EDGE SEALANT IS REQUIRED ON ALL CUT OR NON-ENCAPSULATED EDGES OF REINFORCED MEMBRANE. THIS INCLUDES FACTORY CUT MEMBRANE.
3. DUCT TAPE MAY BE SUBSTITUTED FOR FOIL TAPE.

**MULE-HIDE
PRODUCTS CO., INC.**
04/01/2007

**INSIDE CORNER WITH
COATED METAL WALL FLASHING
SYSTEMS:
ALL PVC**

**DETAIL NO:
MHP-185**