



NOTE:

NOT APPROVED FOR 20-YEAR SYSTEM WARRANTIES OR FOR USE IN HIGH WIND AREAS

NOTES:

1. REFER TO METAL RETROFIT SPECS FOR PROPER WOOD NAILER FASTENING CRITERIA.
2. INSPECT THE STRUCTURAL INTEGRITY OF EXISTING STEEL MEMBER(S) PRIOR TO ANCHORING NEW WOOD BLOCKING.
3. THICKNESS OF WOOD NAILER(S) TO MATCH THICKNESS OF NEW INSULATION.
4. SEE MMRT-109 FOR METAL EDGE INSTALLATION AND REQUIREMENTS OF ANSI/SPRI ES-1 COMPLIANCE.
5. FASTENERS USED TO ATTACH SHEET METAL MUST PENETRATE WOOD NAILER A MINIMUM OF 1/4". IF PLYWOOD IS USED AS THE TOP LAYER, FASTENERS MUST PENETRATE A MINIMUM OF 1/4" INTO WOOD NAILER BELOW.
6. APPROXIMATELY 1/8" DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED TPO MEMBRANE.
7. GUTTER FASTENERS & FASTENERS' PATTERN AS RECOMMENDED BY GUTTER MANUFACTURER.

**MULE-HIDE
PRODUCTS CO., INC.
2011**

**MEMBRANE COATED DRIP EDGE
WITH GUTTER
SYSTEMS:
METAL RETROFIT
TPO MECHANICALLY ATTACHED**

**DETAIL NO.:
MMRT-103**