



NOTES:

1. REFER TO METAL RETROFIT SPECS FOR PROPER WOOD NAILER FASTENING CRITERIA.
2. INSPECT THE STRUCTURAL INTEGRITY OF EXISTING STEEL MEMBER(S) PRIOR TO ANCHORING NEW WOOD BLOCKING.
3. THICKNESS OF WOOD NAILER(S) TO MATCH THE THICKNESS OF NEW INSULATION.
4. FASTENERS USED TO ATTACH SHEET METAL MUST PENETRATE WOOD NAILER A MINIMUM OF 1/4". IF PLYWOOD IS USED AS THE TOP LAYER, FASTENERS MUST PENETRATE A MINIMUM OF 1/4" INTO WOOD NAILER BELOW.
5. TO REMOVE FINISHING OILS AT NON-COATED METALS, SCRUB METAL FLANGE WITH WEATHERED MEMBRANE CLEANER AND ALLOW TO DRY PRIOR TO THE APPLICATION OF TAPE PRIMER.
6. APPLY TAPE PRIMER TO METAL FLANGE AND TPO MEMBRANE SURFACE PRIOR TO INSTALLING PRESSURE-SENSITIVE CURED COVER STRIP.
7. REFER TO METAL RETROFIT SPEC FOR PROPER MEMBRANE SPLICING PROCEDURES.

NOTE:

THIS DETAIL APPROVED FOR 20-YEAR SYSTEM WARRANTIES.

**MULE-HIDE  
PRODUCTS CO., INC.  
2011**

**RAKE DRIP EDGE  
WITH PRESSURE SENSITIVE COVER STRIP  
SYSTEMS:  
METAL RETROFIT  
TPO MECHANICALLY ATTACHED**

**DETAIL NO.:  
MMRT-102**