


# PARAPET WALL FLASHING SURFACE TERMINATION

TOP OF FLASHINGS MUST BE MECHANICALLY TERMINATED. "J" STYLE METAL/MATERIAL USED IN CONJUNCTION WITH AN EXTERIOR FINISH MATERIAL (NEW STUCCO OR SIDING) MAY BE INSTALLED OVER THE FLASHINGS (ACTING AS A TERMINATION BAR) WITH APPROPRIATE FASTENERS SPACED 8" ON CENTER. THE FASTENERS MUST PENETRATE AND ANCHOR INTO THE STRUCTURAL WALL (CONCRETE, WOOD, BLOCK, ETC.)

SA-SBS CAP SHEET  
OR SA-APP CAP SHEET

8" min

6"



CAP SHEET MUST TURN UP THE VERTICAL SURFACE A MINIMUM OF 4".

MULE-HIDE DOES NOT REQUIRE BUT RECOMMENDS CANTS (CANTS ARE OPTIONAL). THE VERTICAL SURFACE OF THE CAP SHEET MUST BE SOFTENED OR MUST BE COATED WITH MOD BIT FLASHING ADHESIVE PRIOR TO INSTALLING FLASHING MATERIAL.

**NOTES:**

1. VERTICAL SURFACES SUCH AS MASONRY, STUCCO, CONCRETE, AGED WOOD OR METAL SHALL BE PRIMED WITH MULE-HIDE # 121 ASPHALT PRIMER. PRIMER MUST BE THOROUGHLY DRY BEFORE APPLICATION OF SELF-ADHERING MEMBRANES.

**MULE-HIDE  
PRODUCTS CO.,INC.  
2003**

**WALL FLASHING TERMINATION - 2**

**SELF-ADHERING MOD BIT SYSTEMS**

**DETAIL NO.:  
MH-MB-WFT02**